



Tol. grades IT	Nominal size range												
	— ... 3	>3 ... 6	>6 ... 10	>10 ... 18	>18 ... 30	>30 ... 50	>50 ... 80	>80 ... 120	>120 ... 180	>180 ... 250	>250 ... 315	>315 ... 400	>400 ... 500
01	0,3	0,4	0,4	0,5	0,6	0,6	0,8	1	1,2	2	2,5	3	4
0	0,5	0,6	0,6	0,8	1	1	1,2	1,5	2	3	4	5	6
1	0,8	1	1	1,2	1,5	1,5	2	2,5	3,5	4,5	6	7	8
2	1,2	1,5	1,5	2	2,5	2,5	3	4	5	7	8	9	10
3	2	2,5	2,5	3	4	4	5	6	8	10	12	13	15
4	3	4	4	5	6	7	8	10	12	14	16	18	20
5	4	5	6	8	9	11	13	15	18	20	23	25	27
6	6	8	9	11	13	16	19	22	25	29	32	36	40
7	10	12	15	18	21	25	30	35	40	46	52	57	63
8	14	18	22	27	33	39	46	54	63	72	81	89	97
9	25	30	36	43	52	62	74	87	100	115	130	140	155
10	40	48	58	70	84	100	120	140	160	185	210	230	250
11	60	75	90	110	130	160	190	220	250	290	320	360	400
12	100	120	150	180	210	250	300	350	400	460	520	570	630
13	140	180	220	270	330	390	460	540	630	720	810	890	970
14	250	300	360	430	520	620	740	870	1000	1150	1300	1400	1550
15	400	480	580	700	840	1000	1200	1400	1600	1850	2100	2300	2500
16	600	750	900	1100	1300	1600	1900	2200	2500	2900	3200	3600	4000
17	1000	1200	1500	1800	2100	2500	3000	3500	4000	4600	5200	5700	6300
18	1400	1800	2200	2700	3300	3900	4600	5400	6300	7200	8100	2200	9700

Tolerances in µm

Description

This ISO Standard represents the basis for a system of limiting sizes and fits whereby the table mirrors the calculated values of fundamental tolerances in connection with fundamental dimensions.

The use of this table is limited to smooth circular cylindrical workpieces or such with two parallel fitting planes or contact areas.

The numerical values attributed to an ISO tolerance grade (IT) specify the size of the tolerance and hence the tolerance field. With ascending numbers, the size of the tolerance increases.

For identification purposes of the position of the tolerance field in relation to the nominal dimension (zero), the number chosen as tolerance grade IT is preceded by a letter.

Tolerance area H is the most common value for bores. It specifies that the minimum dimension of the bore corresponds to the nominal dimension. The permissible maximum dimension corresponds to the nominal dimension plus the IT tolerance.

Examples

Bore 20 H7 = $20 \begin{smallmatrix} +0,021 \\ 0 \end{smallmatrix}$
 min. dimension: 20,000
 max. dimension: 20,021

Bore 8 H11 = $8 \begin{smallmatrix} +0,090 \\ 0 \end{smallmatrix}$
 min. dimension: 8,000
 max. dimension: 8,090

